




# wooden art easel

assembly instructions


1145050506  
Early Learning Centre®  
Swindon SN3 4TJ England.

Customer Service Department  
01793 443322


## contents




(A) x1




(D) x1



(E) x1




(F) x2




(B) x1




(G) x2




(K) x1



(H) x2




(L) x1




(C) x1



(I) x4




(J) x12




(M) x6

assembly


1



2



3



4

