




bubble whale

user guide


145301/145302 1116
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0371 231 3513


how to play




1. Pour bubble mixture into the bubble machine below the mark of max level.



2. Press button to start / stop.



3. Turn off the bubble machine after each use. Pour out the remaining bubble solution. Do not submerge the bubble machine in water, do not leave bubble solution in the bubble machine.



Warning! Bubble mixture can leave a slippery deposit in front of the machine. We recommend that you do not allow children to play directly in front of the machine and that the area is cleaned thoroughly after use.

* Bubble mixture is not included.