




cool keyboard

instructions

112972 0306
Early Learning Centre®
Swindon SN3 4TJ England.

Customer Service Department
01793 443322

features



- 1 On/Off switch
- 2 Stop
- 3 Piano
- 4 Organ
- 5 Violin
- 6 Trumpet
- 7 Mandolin
- 8 Bell
- 9 Music box
- 10 Guitar
- 11 Volume control
- 12 Drum / Dog sound
- 13 Drum / Frog sound
- 14 Drum / Duck sound
- 15 Cymbals / Chick sound
- 16 Change key
- 17 Demo All button
- 18 Demo Selection button
- 19 Record button *
- 20 Play button
- 21 March
- 22 Waltz
- 23 Samba
- 24 Blues
- 25 Slow Rock
- 26 Rock
- 27 New Age
- 28 Disco
- 29 Tempo buttons
- 30 Press any key to make it flash

19 * Press 'record' button to start the record function. Compose your music using the keyboard. Press the play button to hear your recording.

Note: If the unit is idle for about 2 minutes, it will switch off automatically. In the unlikely event of this toy malfunctioning, reset the toy by turning off and on again.

SKU no. 112972
Name cool keyboard boy
Buying team M&L
Designer James
Date created 03.03.06

Head Check	Yes	No	Head Check	Yes	No	Head Check	Yes	No
Body/Engine Check	Yes	No	Body/Engine Check	Yes	No	Body/Engine Check	Yes	No
Control Panel Check	Yes	No	Control Panel Check	Yes	No	Control Panel Check	Yes	No
Function Manager	Yes	No	Function Manager	Yes	No	Function Manager	Yes	No
Head Check	Yes	No	Head Check	Yes	No	Head Check	Yes	No
Body/Engine Check	Yes	No	Body/Engine Check	Yes	No	Body/Engine Check	Yes	No
Control Panel Check	Yes	No	Control Panel Check	Yes	No	Control Panel Check	Yes	No
Function Manager	Yes	No	Function Manager	Yes	No	Function Manager	Yes	No

AW06