



Adult assembly required




Doll's High Chair

SKU:109531

Early Learning Centre® Swindon SN3 4TJ England
Customer Service Department 01793 443322


Contents Note: Please read instructions before starting to assemble

A




x1

B




x1

C



x1

D




x1

E



x2

F



x1

G




x1

H




x9


1




2



3



4



5

