

MAGIC STICKER MAKER™

FEATURES AND FUNCTIONS

Your Xyron® Magic Sticker Maker™ comes loaded with a cartridge of removable adhesive ready to use right out of the box. Refill cartridges are available from the Early Learning Centre.

BASIC OPERATION AS EASY AS 1-2-3!

STEP 1




Place a shape on the feed tray face up. Gently push the shape forward until it touches the adhesive cartridge.

STEP 2



Pull the strip up against the built in


STEP 3



Peel the shape from the strip, then stick it onto your project.

HOW TO CHANGE THE CARTRIDGE:

STEP 1



Pull the latch up to open the lid. Grab the refill cartridge with your fingers then lift the cartridge up to remove. Open the new cartridge and position it as shown in the photo.

STEP 2




Slide the refill cartridge down into the machine. To close, press down on the lid until it clicks. That's all there is to it! Get ready for more fun!

SPECIAL TIPS

- Make sure the refill cartridge is installed correctly before using the machine
- For best results, turn the handle slowly
- Place the shapes close together on the tray, but don't overlap them
- Use items that are 3mm thick or less
- If there is excess adhesive around an item, wipe it away with your finger. The adhesive will come off your finger without sticking


Refill packs of the sticker film are available in Early Learning Centre stores.

3. Once the paper starts to come out of the front remove the plate using the cutter mechanism **D**. To prevent the paper jams make sure the cutter is pushed right to the end of the slot before turning the handle.




3


d) Turn the square plastic plate over and feed between the rollers by turning the handle. As the plate comes out of the front of the machine gently pull it out whilst continuing to turn the handle.



c) Position the sticker film roll in the sticker station with the adhesive side facing upwards.




1. Insert the sticker paper with the peel off adhesive backing facing downwards. Feed the end of the paper under the paper guides **A** so that the end of the roll is touching the rollers.




1

b) Stick the square plastic plate **C** to the edge of the sticker film.



a) Insert the spindle **B** into the centre of the roll of transparent sticker film.



2

Note: Setting up the sticker station (steps 1-4) is quite difficult and will require the assistance of an adult.

How to set up the sticker station

STICKER STATION



4 years +