











3 years +

# Remote Control Racers


## Charging instructions

<p><b>1</b> Remove the car charger from the bottom of the I.R. controller.</p>  <p>Press to release</p>	<p><b>2</b> Slide the switch on the car to "OFF". Fit the car on the charger as shown. Slide the switch on the charger to "ON".</p> 	<p><b>3</b> Red light : charging Green light : fully charged</p> 
<p><b>4</b> Remove the car from the charger. Replace the charger on the I.R. controller. (this is the power supply)</p> 	<p><b>5</b> Slide the switch on the car to "ON". You can now control your racer.</p> 	
<p><b>6</b> One 3 minute charge gives you 11-13 minutes play.</p> 	<p><b>7</b> Store your racer in the transparent bubble of the IR controller after play.</p> 	



**IR Channel selection**

Slide the switch to the number shown on the car chassis.



**Speed Control**  
2 speed selection: normal/turbo

**Trim adjustment**

The car is factory set to travel in a straight line. If you find it going off-centre adjust the trim with a small screwdriver.



If the car loses the IR signal, the headlamps will flash. Reposition the controller for a better signal.

