




# rock star guitar

instructions

112978 0406  
Early Learning Centre®  
Swindon SN3 4TJ England.

Customer Service Department  
01793 443322

## features:



### Power on/off

Slide the on/off switch to turn the unit on.

### Demo button

Press the demo button to hear a demo song.

### Melody and sound effects button

Press the buttons to hear different melodies and sounds.

### Swing bar

Pull the swing bar while playing to hear cool sound effects.

### Drum button

Select your favourite drum beat (drum1, drum2 & drum3).

### Strings

Press the strings for fill in melodies and sound effects

### Stop button:

Press this button to stop all functions

### Automatic shut-off

To preserve battery life, the "rock star guitar" will automatically power-off after several minutes of inactivity. The unit can be turned on again by pressing any button.

### Trouble shooting

If for some reason the unit stops working, please follow these steps:

1. Please turn the unit off.
2. Interrupt the power supply by removing the batteries
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit on. The unit should now be ready to play again.

### Care & maintenance

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.