




# Wooden Pirate Ship



3 years +  
Adult assembly required


SKU:103094

Early Learning Centre® Swindon SN3 4TJ England.  
Customer Service Department 01793 443322

Note: Please read instructions before starting to assemble


## Contents:

**A** Back Wall




x1

**B** Main Hull




x1

**C** Back Wall Screw




x2

**D** Main Deck & Holds




x1

**E** Anchor Assembly




x1

**F** Front Rails




x2

**H** Front Sail




x1

**G** Rear Rails



x2

**I** Main Sail












x1



page 1

610782 V2.0 030528








# Contents:



## Assembly 1



# Assembly 2



# Assembly 3

