



Jungle Sensory Dome

instructions

135737

Early Learning Centre®
Watford WD24 6SH England

Customer Service Department
0371 231 3513



Made in China.
Retain this information for future reference.
Colour and specification of product may vary from that illustrated.

REF: INS.163SDO-EL 09/04/15

WARNING KEEP AWAY FROM FIRE!

⚠ Adult supervision required. Adult assembly required. IMPORTANT! The putting up and taking down of this product should always be done by an adult. The product has an internal spring frame that will 'pop' open with some force. Always place on a cleared flat surface away from sharp object and stones. Never shelter in this product during a thunderstorm. Not waterproof or made for camping. Do not continue to use this product if any part of the frame becomes either bent or broken, immediately contact Early Learning Centre in the event of a failure. IMPORTANT. Wipe clean only. Remove all packaging before giving to your child.

TIP

If the product refuses to "pop" back into shape - follow the steel around the frame sleeve with your fingers, and "twist & flip" the steel band back around into alignment.

Assemble



PLEASE READ ALL INSTRUCTIONS AND WARNINGS BEFORE ASSEMBLY
Take care when folding/unfolding, this product contains an internal spring frame.



• Carefully open out.



• Insert assembled rods



• Fully assembled product. Ready for play.

Fold Away



• Remove rods



• Push downwards and let product curve outwards.



• Still pushing down, twist your right hand inwards and then follow with the left hand allowing the edges to overlap.



• Push in the over hanging coil and then fold down the remaining coil.



• Fold flat and replace into warning band.



9