























little cook's kitchen

user guide

142521/142522 0915
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0371 231 3513

parts checklist

1 x1 	2 x1 	3 x5 	4 x1 
5 x2 	6 x1 	7 x1 	8 x1 
9 x2 	10 x1 	11 x1 	12 x1 
14 x2 	15 x1 	16 x1 	13 x1 
18 x1 	19 x1 	20 x1 	21 x4 

assembly

