



Cupcake Highchair


user guide

143425 0516
Early Learning Centre®
Watford WD24 6SH England.


Customer Service Department
0371 231 3513

assembly


1




2



3



4



5

