




bubble machine

user guide


135420 / 135421 0713
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0871 231 3511


how to play



1. pour bubble mixture into the bubble machine



2. press button to start / stop



3. turn off after use, pour out the bubble mixture and rinse, do not submerge the bubble machine in water.

Warning! Bubble mixture can leave a slippery deposit in front of the machine. We recommend that you do not allow children to play directly in front of the machine and that the area is cleaned thoroughly after use.

* Bubble mixture is not included.