




# my alphabet tablet

instructions

137605 0613  
Early Learning Centre®  
Watford WD24 6SH England.

Customer Service Department  
0871 231 3511



## how to play

Press to turn the tablet on.

Press on the letter images to discover letters and words.

Or

Select a game by pressing on one of the 4 images below:



Press to hear fun melodies!

### discovery mode :

- The aim of this mode is to discover letters and words.
- Press on a letter image to learn the letter and word.

### letter mode :

- The aim of this mode is to find the first letter of the word.
- The tablet will ask the player a selection of questions.
- For example the tablet will ask:  
Find the first letter of the word sock.
- When the correct letter image is pressed, the unit will say "well done."
- When the incorrect letter image is pressed, the unit will say "oops."
- Try to find the correct answer within 3 attempts. After that the unit will tell you the correct answer.

### follow-me mode :

- The aim of this mode is to learn the alphabet.
- The tablet will ask the player a selection of questions.
- For example the tablet will ask:  
Find the letter 's' or Find the letter 'a' etc...
- The player will have to find and press the correct letter image as quickly as possible.
- If the player completes a sequence of 5 letters they win.
- When the incorrect letter image is pressed the tablet will start again.

Note :

The unit will go to sleep if left idle for a while. To wake it up, press the on/off button.

### music mode :

- Press the music mode image and listen to fun melodies.

### spelling quiz :

- The aim of this mode is to learn how to spell.
- The tablet will ask the player a selection of questions.
- For example the tablet will ask:  
Can you spell the word sock or Can you spell the word duck etc...
- The player will have to press on the correct letter image to spell the word.
- You will have 3 attempts per letter to spell the word.
- If you press the incorrect letter image twice, the tablet will tell you which letter to press.
- If you make a mistake on the third try, the tablet will spell the word for you.