



little TV

instructions

137034
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0871 231 3511

contents



how to play

- Before playing, attach the unit legs to the back of the unit.
- To turn the unit on, press the wake-up key or insert a card.
- If a card is already inserted, press the wake-up key to trigger questions related to the card.
- Use the remote control (6 animal keys) to answer the questions. You will have three attempts to answer each question correctly, before you are asked another question.
- Press the repeat key on the controller to hear the question again.
- Press the music key to hear a melody relating to the scene.
- Once you have answered all the questions, change the card to answer some more.
- Automatic shut off : In order to preserve battery life, the unit switches off automatically if left idle for three minutes. To reactivate the unit, just press the wake-up key.
You can also switch the unit off by pressing the wake-up key.