




sing along star microphone

user guide


136785/136786 0413
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0871 231 3511


parts checklist



assembly



how to play



	<ul style="list-style-type: none"> Press the button to hear 5 demo songs and 5 rhythms. The light flashes to the rhythm.
	<ul style="list-style-type: none"> Press the button to hear a "beep," you can then begin to record your voice for a maximum of 5 seconds. Press again to stop or the recording will automatically stop after 5 seconds followed by 2 "beeps."
	<ul style="list-style-type: none"> Press the button to hear the recorded voice once. While the demo song is playing, press the PLAY button to play your recorded voice. While the Echo or Robot button is pressed, press the button to play the recorded voice.
	<ul style="list-style-type: none"> Press the button to hear your recorded voice turn into 3 fun melodies. The light flashes to the rhythm.
	<ul style="list-style-type: none"> Press the button for echo sound effects, press again or another button to go into another mode (otherwise it stays in echo mode). The light flashes in this mode.
	<ul style="list-style-type: none"> Press the button for robot sound effects, press again or another button to go into another mode (otherwise it stays in robot mode). The light flashes in this mode.

* The unit goes to sleep if left idle for 3 minutes. Press any button on the microphone or stand to reactivate the unit.

* Record your voice in a quiet environment to ensure better playback quality.

