



assembly

3



4



studio kitchen
assembly instructions

138368 1013
Early Learning Centre®
Swindon SN3 4TJ England.


Customer Service Department
0871 231 3511

contents - table


A x1	B x1	C x1	D x1
E x1	F x1	G x1	H x1
I x1	J x1	K-1 x1	K-2 x1
L x2	M x1	N x1	O-1 x1
O-2 x1	O-3 x1	O-4 x1	O-5 x1
P-1 x1	P-2 x1	P-3 x1	P-4 x1
P-5 x1	Q-1 x1	Q-2 x1	R x1
S1 x1	S2 x1	T x2	U x4
V-1 x20	V-2 x4	V-3 x36	X x8
Y x3			

assembly


5



6




7



assembly

1



2

