



wooden bunny trike

user guide

137266 0413
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0871 231 3511

parts checklist

WARNING: Adult assembly required. Contains potentially small parts. Keep away from children until assembled.
NOTE: Please read instructions before starting to assemble

A x1 	B x1 	C x1
D x1 	E x1 	F x1
G x4 	H x1 	I x1
J x1 	K x2 	
L x2 	M x1 	N x4
O x4 	P x2 	

