

contents

** Please make sure to count all hardware and components before you begin assembling the product.

AX2 	CX3 	EX2 	GX2 	IX1 	JX1
BX2 	DX3 	FX2 	HX1 		
KX1 	LX2 	NX6 	PX1 	RX1(2 part inside) 	
SX5 	accessories				
	X2	X2	X2	X2	X2
TX1 					
	X1	X1	X1	X1	X1
	X1	X1	X2	X1	X1
	X1	X1	X2	X1	X5



wooden train table
user guide

136727 0313
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0871 231 3511

contents

Adult assembly required
In an unassembled state product contains sharp points which may cause injury if misused. Not suitable for children under 3 years

1 x1 	2 x1 	3 x2 	4 x2 	5 x2 	6 x1 	7 x1
8 x2 	9 x1 	10 x1 	11 x1 	12 x8 	13 x8 	14 x16
				15 x16 	16 x2 	17 x2
						18 x1

** Please make sure to count all hardware and components before you begin assembling the product.

assembly

early learning centre AW13

sku number : 136727
product : Wooden Train Table
pack dimensions : A4
supplier : Tecella category : A&A
date : 27 Mar 2013 designer : Boris Au

colours:



approval	date	signature
packaging manager		
copywriter		
QA		
product manager		

NOTE: The spot colour is not accurate (simulated using CMYK) in this digital proof. please refer to the Pantone specification (or our colour key).