




moves and grooves dance mat

instructions

113781 0306
Early Learning Centre®
Swindon SN3 4TJ England.

Customer Service Department
08705 352352

how to play



① On / Off button

Press the button to turn on and off the Double Dance Mat

Two separate short tunes will play when the dance mat is turned on and off.

② One player / two player mode

Press the button to switch between the two modes. One light will blink in the one player mode. Two lights will blink in the two-player mode.

The item will always be preset in the one player mode when turned on.

③ Free Play Button

The child can choose between four funky melodies by pushing the button to scroll. When the melody begins to play, the child can dance on any of the four pads and two feet to activate additional musical sounds and make the lights on the console flash.


The two feet only make sounds in the Free Play mode.

④ Follow Me Button


Choose one of the four melody options by pushing the button to scroll. The music will begin to play, and after a few seconds, the light(s) on the console will start to flash, the object of the game is for the child to jump simultaneously on one or two of the four corresponding pads. The melody and the flashing lights will gradually speed up and if the child steps on the wrong pad, or if the child is too slow to step on the pad, then a losing sound will play. The child must push the Follow Me button to play again.

In one player mode, a special winning sound will play if the player completes the game.

In two-player mode, the player who makes a mistake first will lose the game, the light on the winner's side will blink and the music will stop. A winning sound will play and two lights will blink if both players complete the game.



In one player mode, the player must stand on the side with the "one player" flashing light.



In two-player mode, the players should stand in the middle of the mat while facing each other when they start the game.

Note: Item turns off automatically after approximately 1 minute of inactivity