




# safety set user guide

140315/140316 0416

Early Learning Centre®  
Watford WD24 6SH England.

Customer Service Department  
0371 231 3513

Before you use your new helmet, please read through these instructions and familiarise yourself with its safe and appropriate use.



### How to fit your helmet.

For children adult supervision is strongly recommended to ensure the correct fitting of the helmet. To ensure a proper fit, look in the mirror and gently rotate the helmet on your head, front to back and side to side. Notice the skin in the brow area. If the fit is comfortable and the skin moves with the helmet a proper fit has been accomplished. If not the helmet is too loose. The helmet should be worn with the front approximately 2.5cm from your eyebrows. Place the helmet front to back on your head as shown in figure 1.

### How to fit the straps:

Adjust the length of the straps as shown in figure 2 and fasten the buckle as shown in figure 3. Check the strap length again to make certain the strap is adjusted properly. The strap should be secure but comfortable under the chin. The helmet should be level and secure on the head. Test the overall fit of the helmet with the strap secured. Push the helmet from front to back and from side to side. Readjust the strap tension and the pad placement until the helmet is secure and does not slide or move from its level position as seen in figure 1.

**Note:** The straps should never cover the ears and the buckles should be positioned away from the jaw bone. If a proper fit cannot be achieved do not wear the helmet, instead purchase and wear a helmet that gives the best fit.

**Warning:** This helmet should only be worn when using bicycles, roller skates, in-line skates and skate boards. The helmet should not be worn for any other activity such as climbing or other activities where there is a risk of hanging and/or suffocation should the child get trapped or in difficulty.

### SAFETY

Please carefully read and understand the information below. Be sure that all users of this item have read and understood the information below:

- This helmet can only protect if it fits well. Consumers should try different sizes and choose the size of the helmet which feels secure and comfortable on the head.
- The helmet should be adjusted to fit the user comfortably e.g. the straps should be positioned so that they do not cover the ears and the buckle should be positioned away from the jawbone with the straps and the buckle adjusted to be both comfortable and firm.
- The helmet should be positioned on the head to ensure the intended protection is provided (e.g. the helmet should be placed so as to protect the forehead and not be pushed too far over the back of the head).
- Please be aware that a helmet cannot always protect against injury.
- If this helmet is subjected to a severe impact then it should be discarded and destroyed.
- It is dangerous to modify or remove any of the original component parts of the helmet and helmets should not be adapted from their original design. Accessories should not be fitted either. All of these activities can adversely affect the integrity of the helmet.

### WARNING

The helmets designed for the following use only:

Pedal cycling, roller and in-line skating and skate boarding. Never use this helmet on motor vehicles or for similar activities that would be subject to motor vehicle speed. For maximum protection the helmet must be fitted properly and all retention straps must be correctly and securely fastened.

This helmet is designed for single impact protection and should never be used after an accident. Never modify or remove any of the original parts of the helmet. Never adapt the helmet for the purpose of fitting accessories.

Never repaint the helmet as this may damage its structural integrity.

Never apply solvents, thinners, bensine or alcohol as they may damage the protective cover.

Do not expose the helmet to extreme temperatures.

To clean your helmet, gently wash with mild soap, water and a nonabrasive cloth.

This helmet provides no protection to parts of the body that it does not cover directly.

This helmet is not for use of persons who can not comfortably support the helmets weight.


Baring a significant impact, the life span of a helmet will depend upon the length and frequency of its use. Like other safety devices a skate helmet needs to be replaced overtime. We recommend evaluating your helmet after three years of use.



Please retain for future reference

Made in China

Before you use your new pad set, please read through these instructions and familiarise yourself with its safe and appropriate use.



### Choosing your protector.

Once you have selected a pad, place it against your elbow or knee (pay attention to the left-right marking on the pad where necessary) to make sure it is the proper size

It's important that the pad fits correctly and is comfortable so that it doesn't slip.

Place the pad on your elbow or knee so that the protection area faces outward. Use the hook and loop closure. Do not fasten the hook and loop closure too tightly or in a way that restricts blood circulation.

### How to use:

1. Unfasten the restraining straps.
2. Select the correct pad and insert arm or leg until the pad is positioned over the elbow or knee joint.
3. Re-attach the restraining straps ensuring a secure and snug fit.

### Warning!

No protector can offer full protection against injuries.

Never use with straps unfastened.

Do not modify the protector, it could reduce the performance and protection of the protector.

3 ranges of body mass as follows:

✓ Range A: User of up to 25kg body mass

Range B: Users of body mass more than 25kg to 50kg

Range C: Users of body mass above 50kg

### Cleaning and Care:

Store in a cool dry place

Wash carefully by hand at max 30°C.

Do not machine wash.

Leave to dry at room temperature. Do not place close to radiator or any other source of heat.

Keep away from strong sunlight.

### Inspection:

Before using the pad, inspect it carefully-visually and by hand. If the protector no longer feels secure or is showing signs of heavy usage, please discard as its performance maybe reduced after a period of time.

### WARNING

The pads are not intended to provide protection in the event of a serious fall when travelling at speeds in excess of 12km/h. These pads help protect against superficial grazing and minor impact.

Carefully examine for damage to pads or tears to fabric. If damaged dispose of item and do not use.

Do not store in direct sunlight.

Wipe clean with a mild detergent.

✓ Level 1: Protective intended to be suitable for normal roller sports.

Level 2: Protectors intended to be suitable for use in acrobatic roller sports

Adult supervision is recommended during fitting.

Please be aware that changes in environmental conditions such as temperature can significantly reduce the performance of the protectors.

Please use this product in the manner it was intended. Any miss use or alteration of the design can dangerously reduce the performance of the protector.

Using the adjustable straps please fit these protectors so that they provide a comfortable but close and secure fit. Please note that no protector can offer full protection against injury.

Level 1: Protective intended to be suitable for normal roller sports.

Range A : Users of up to 25kg body mass

**Material:** 15% Elastic. 20% Nylon. 50% EVA Foam. 5% Resin. 1.5% TPR

EN14120:2003+A1:2007 LEVEL 1,SIZE:L

Manufacture year: 2014

Item No: 140315/140316



Please retain for future reference

Made in China