



2-in-1 skates


user guide

140321 / 140322 0416

Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0371 231 3513

contents





Warning! Protective equipment should be worn. Not to be used in traffic. Max weight 20kg. These skates should be used under adult supervision and with caution since skill is required to avoid falls or collisions causing injury to the user or third parties. Ensure all parts are securely assembled & tightened before use. To operate brake, gently but firmly depress heel. Never use in roadways, near steps or steep inclines or near pools or open bodies of water. Protective equipment should be worn such as a helmet, gloves, knee and elbow pads.

how to play

How to change trainer skate to inline skate

1. First remove the back wheels by using both Allen keys. Loosen, and then remove the screws and axle that hold the back wheels.
2. Insert the rear wheel inside the rear part of the chassis and slot the smaller bolt (provided) through the chassis and wheel, then tighten with the Allen keys.
3. Repeat for the middle wheel.
4. Check all nuts and bolts to make sure they are secure.
5. Store all remaining parts for future use.



How to adjust boot size

1. First, remove the liner from the boot. Adjust the Velcro sections of the liner around your foot to the desired size, then put the liner back into the skate.
2. Locate the push clip on the side of the chassis.
3. a) Lift up clip.
b) Turn clip to loosen the bolt. Do not unscrew completely.
c) When loose, move boot to the proper position.
d) Tighten clip securely.
e) Press clip flat.

